

Twice the Life and Better Protection

New Dynamic Window Module (DWM) for Sindie Online

NEW BENEFITS

- Double the time between DWM refurbishments saving time and money
- Improved film protection nearly eliminates risk of environmental contamination

NEW FEATURES

- Twice the window film compared to previous generation DWM
- Better film guidance and new cylindrical rollers ensure smooth operation
- Optimized coil spring force applied to sample chamber reduces strain, reducing risk of window film breaks

HASSLE-FREE ONLINE SULFUR ANALYSIS

The DWM serves as the sample measurement chamber and automatically changes the measurement window every 2-4 hours to prevent sulfur buildup. It delivers continuous measurement for up to a year without maintenance. When the film requires replenishment, it is as simple as loosening four bolts and replacing with a refurbished DWM.

